



THALASSA EVO 800 FALI PÁRAELSZÍVÓ

EN USE INSTRUCTIONS
HU HASZNÁLATI ÚTMUTATÓ



cata 
green innovation



⚠ WARNING: Read the instructions before using the appliance

FUNCTIONS & SETTINGS

CONTROL PANEL

To obtain the best results from your cooker hood it is recommended that you leave it switched on for a short time after you have finished cooking.

	Timer
	ON, Fan Boost Function and Fan speed increase
	LED display
	OFF and Fan speed decrease
	Light ON /OFF

SETTINGS

Once the appliance is switched off press both, increase () and decrease fan speed () icons. All icons will start blinking in White. The hood is now in setting mode.

! IMPORTANT: Once in settings mode, you can adjust the recirculation and lighting options in any order. However, all actions must be completed within two minutes.

SETTING THE DUCTED OR RECIRCULATION MODE

Once in setting mode, press the Timer () icon and it will blink in red. The LED display will show the current Ducted or Recirculation mode.

Ducted mode: () Default setting to extract air to the outside.

Recirculation mode: () Setting to recirculate the air with carbon filters installed.

To change this option press either () or () to select the correct mode and then press Timer () icon to accept the change.

SETTING THE LIGHTING MODE

Once in setting mode, press the Light () icon and it will blink in red. The LED display will show the current lighting mode.

Cool light: () Default setting for all lights.

Warm light: () Optional setting for all lights.

To change these settings press () or () and press the Light () icon to accept the change.

SETTING CONNECTIVITY MODE

Once in setting mode, press both, the Timer () and the Light () icons. The led display will show (A) blinking waiting hob's signal. Once it receive it, the led display will show (A) fixed.

Note: If the hood controls are manually overridden when the hob and hood are linked, the hood will operate for 5 minutes on this manual setting before returning to control by de hob.

Note: The remote control supplied will already be paired to your ceiling hood.

GENERAL USE

ON/OFF AND INCREASE/DECREASE THE FAN SPEED

Press the decrease fan speed () icon and the fan will turn on at speed 1.

Press the increase fan speed icon () and the fan will turn on at maximum speed (Booster)

If the fan motor is set at speeds 2,3,4, 5 or P, pressing the Fan Decrease () Icon will reduce the speed by one level at a time. If you press the Fan Decrease () Icon for more than three seconds, the fan will turn down. However, the downlight will remain on 8 if enabled).

If the fan motor is set at speed 1, pressing the Fan Decrease () Icon the motor will switch off. However, the downlight will remain on (if enabled) and the display will show the current brightness level.

Boost Function

If the fan motor is set at speeds 1,2,3,4 or 5, pressing the Fan Increase () Icon will increase the speed by one at a time. If you press the Fan Increase () Icon for more than two seconds, the speed will increase to full power from any level and the display will flash "P"

NOTA: Full power or Boost (P) only operates for five minutes maximum to conserve energy and the fan speed will automatically drop to speed level 5 after this time.

Light On/Off ()

Touch the Light () Icon to turn on the downlight.

To change the brightness of the downlight, touch and hold the Light () Icon until the display show the brightness sequence. Remove your finger from the Light () Icon when the desired brightness is achieved. The sequence runs from L1 to L5 and back to L1 in steps. The selected brightness will flash for a few seconds and revert to the fan speed display. This lighting setting will be kept for future uses.

Setting the timer ()

- When the fan motor is on and the Timer (), icon is pressed the icon will turn in red and the display will show the current fan speed.
- The chosen speed level will remain in use for five minutes before dropping down to the next lowest speed. This speed will remain in operation for two minutes before dropping down again. This will be repeated every two minutes unless the speed is already at level 1 and then the fan will turn off. If the light is already on, this will also be turned off.
- Pressing the Fan Decrease () Icon or Fan Increase () Icon during a current timer program will restart the countdown process again with the first five minutes cycle.
- If the Timer () icon is pressed again during a current timer program, the cycle will be cancelled. The Timer () Icon will revert to white and the current fan speed will remain on indefinitely.
- The maximum timer program cycle is 15 minutes: 5 minutes: 5 minutes on 0 and then 2 minutes each on speed 5 down to speed 1.

RENOVA AIR FUNCTION (This function is not available on all models)

Press the timer button () with the hood switched off. A flashing  will appear.

You will have activated Renova Air mode. The hood will operate automatically for 10 minutes every hour. In idle mode, a flashing  icon will appear for 1 hour.

With this mode activated, the hood can be used as normal. To exit this mode, press the timer button () within the function.

RENOVA TURBO FUNCTION

With the hood switched off. Press and hold the timer and increase speed buttons ( ) at the same time for 3 seconds.

A permanent  icon will appear on the display. You have activated the Renova Turbo function.

The  icon will start to flash from bottom to top while this function is activated.

At this time, the hood will continue with the following sequence automatically:

- 5 minutes at MAX speed
- 3 minutes at 5th speed
- 3 minutes at 4th speed

This sequence will continue down to the first speed. Once the time has come to an end, the hood will stop.

To exit this mode before it ends, press the timer icon ().

During Renova mode, the hood can be used as normal by pressing the () or () icons.

The speed of the Renova function can be increased () or () decreased by pressing the or icons. The Renova function will automatically continue with the sequence described above from the selected speed.

Filter cleaning warning

Once the cooker hood is off, if the Timer icon () blinks in red and LED display shows “()”, you should clean the filters. Once they are cleaned or replaced, press the Timer () icon again and the icon will turn off.

(Only in Recirculation mode). Once the cooker hood is off, if Timer () icon blinks in red and the LED display shows “()”, you should clean the carbon filters (in case you are using washable carbon filters) or replace them (in case you are using disposable carbon filters). Once they are cleaned or replaced, press the Timer () icon again and the icon will turn off.



FAQS

Problem	Possible cause	Solution
Excessive vibration.	The appliance is not installed properly on the brackets.	Take down the appliance and check it is properly fixed.
	The fan blade is damaged.	
	The fan motor is not fixed tightly.	
The light is on, but the fan does not work.	The fan blade is jammed.	Switch off the appliance. Repair to be carried out by qualified service personnel only.
	The motor is damaged.	
Both the light and motor do not work.	Light bulb blown.	Contact Customer Services on.
	Power connection loose.	Check power supply.
Suction performance reduced.	Speed may be too low.	Select a higher speed.
	Optional vent kit might be twisted.	Ensure that the vent kit is fitted according to the manufacturer's instructions.
	Top vent might be obstructed.	Clear any obstruction.
	The installation may not comply with the manufacturers instructions.	The vent hose should be correct diameter throughout with no reductions or restriction. (See installation section).
Works normally but cooking smells linger.	Carbon filter is not fitted in recirculation mode or is full of grease.	Fit carbon filter or replace the carbon filter (See Care and maintenance section).
The hood does not work	Check that the hood is connected to power. Check that the fuses or automatic have not jumped.	
The hood still does not work	If, after having checked the points mentioned above, your problem has not yet been solved, contact the technical service or your distributor.	

Hideg fény: (☐) Minden lámpa alapértelmezett beállítása.

Meleg fény: (☐) Választható beállítás minden lámpához.

A beállítások módosításához nyomja meg a (↓) vagy (↑) gombot, majd az elfogadáshoz nyomja meg a Világítás (💡) ikont.

CSATLAKOZÁSI MÓD BEÁLLÍTÁSA

A beállítási módban egyszerre nyomja meg az Időzítő (⌚) és a Világítás (💡) ikonokat . A Led-kijelző villogó (A) jelet mutat, jelezve, hogy a készülék a főzőlap jelére vár. Amint megkapja a jelet, az LED-kijelző (A) állandóan világítani fog.

Megjegyzés: Ha a főzőlap és a páraelszívó összekapcsolása közben manuálisan felülbírálja a páraelszívó vezérlését, a páraelszívó 5 percig ezen a manuális beállításon fog működni, mielőtt visszatér a főzőlap általi vezérléshez.

Megjegyzés: A mellékelt távirányító már párosítva van a mennyezeti páraelszívóval.

ÁLTALÁNOS HASZNÁLAT

BE/KI ÉS VENTILÁTOR SEBESSÉG NÖVELESE/CSÖKKENTÉSE

Nyomja meg a ventilátorsebesség csökkentése (↓) ikont, és a ventilátor 1- es fokozaton indul el.

Nyomja meg a ventilátorsebesség növeléséhez a (↑) ikont és a ventilátor a maximális sebességen (Turbó) indul.

Ha a ventilátormotor 2, 3, 4, 5 vagy P sebességen van, a ventilátorsebesség csökkentése (↓) ikon megnyomásával a sebesség fokozatosan csökken egy szinttel. Ha a lefele mutató (↓) nyilat három másodpercnél tovább nyomva tartja, a ventilátor leáll. Az alsó lámpák azonban továbbra is világítanak (ha aktívak voltak).

Ha a ventilátormotor az 1-es sebességen van, a ventilátorsebesség csökkentése (↓) ikon megnyomásával a motor kikapcsol. A LED világítás (ha be van kapcsolva) továbbra is világít, és a kijelző megmutatja az aktuális fényerőszintet.

Turbó funkció

Ha a ventilátormotor 1, 2, 3, 4 vagy 5-ös sebességre van állítva, a Ventilátor sebesség növelése (↑) ikon megnyomásával a sebesség egyesével növelhet ő.

Ha a Ventilátorsebesség növelése (↑) ikont két másodpercnél tovább nyomja, a sebesség bármely szintről maximális teljesítményre vált, és a kijelzőn villogni kezd a „ P ” betű.”

- 6 MEGJEGYZÉS:** A max. teljesítmény vagy a turbó (P) funkció legfeljebb öt percig működik az energia megtakarítása érdekében, majd ezután a ventilátor sebessége automatikusan visszaáll az 5-ös szintre.

Világítás Be/Ki (💡)

Érintse meg a Világítás (💡) ikont a lámpa bekapcsolásához.

A lefelé világító lámpa fényerejének módosításához érintse meg és tartsa lenyomva a Világítás (💡) ikont, amíg a kijelzőn meg nem jelenik a fényerő-szabályozási sáv. Vegye le az ujját a Világítás (💡) ikonról, amikor elérte a kívánt fényerőt. A fokozat beállítása L1-től L5-ig, majd vissza L1-ig lépésenként halad. A kiválasztott fényerő néhány másodpercig villog, majd visszatér a ventilátorsebesség kijelzéséhez. Ez a világítási beállítás megmarad a későbbi használatkor is.

Időzítő beállítása (⌚)

- Amikor a ventilátormotor be van kapcsolva, és megnyomja az Időzítő (⌚) ikont, az ikon pirosra vált, és a kijelző megjeleníti az aktuális ventilátorsebességet.
- A kiválasztott sebességszint öt percig marad aktív, majd automatikusan egy szinttel alacsonyabbra vált. Ez az új sebességszint két percig működik, majd ismét egy szinttel csökken. Ez a folyamat minden két percben megismétlődik, amíg el nem éri az 1-es szintet, ekkor a ventilátor kikapcsol. Ha a világítás már be van kapcsolva, az is kikapcsol.
- Ha egy aktuális időzítő program közben megnyomja a Ventilátor sebesség csökkentése (↓) vagy a Ventilátor sebesség növelése (↑) ikont, a visszaszámlálás az első öt perces ciklussal újraindul.
- Ha egy aktuális időzítőprogram közben ismét megnyomja az Időzítő (⌚) ikont, a ciklus törölődik. Az Időzítő (⌚) ikon visszavált fehérre, és az aktuális ventilátorsebesség korlátlan ideig bekapcsolva marad.
- A maximális időzítő programciklus 15 perc: 5 perc teljes teljesítmény, majd 5 perc 0-ás sebességen, ezt követően 2 percenként csökken a sebesség az 5-ös szinttől az 1-es szintig.

RENOVA AIR FUNKCIÓ (Ez a funkció nem érhető el minden modellnél)

Nyomja meg az Időzítő (⌚) gombot, miközben a páraelszívó ki van kapcsolva. Egy villogó (⏻) ikon jelenik meg. Ezzel aktiválta a Renova Air üzemmódot. A páraelszívó óránként automatikusan 10 percig működik. Készenléti üzemmódban egy órán át (⏻) villogó ikon jelenik meg.

Ebben az üzemmódban a páraelszívó normál módon is használható. A mód kikapcsolásához nyomja meg az Időzítő (⌚) gombot a funkció működése közben.

RENOVA TURBÓ FUNKCIÓ

A páraelszívó kikapcsolt állapotában. Tartsa lenyomva egyszerre az időzítő (⌚) és a ventilátor sebességnövelő gombot (↑) 3 másodpercig.

A kijelzőn egy új (≡) ikon jelenik meg. Ezzel aktiválta a Renova Turbo funkciót.

Az ☐ ikon alulról felfelé villogni kezd, amíg ez a funkció aktív.

Ekkor a páraelszívó automatikusan a következő sorrendben folytatja a műveletet:

- 5 perc maximális sebességen
- 3 perc 5-ös sebességen
- 3 perc 4-es sebességen

Ez a folyamat folyamatosan csökken a legalacsonyabb sebességig. Amint az idő lejár, a páraelszívó leáll.

A Renova mód idő előtti kilépéséhez, nyomja meg az időzítő ikont (☺).

A Renova üzemmód alatt a páraelszívó normál módon is használható a (↑) vagy (↓) ikonok megnyomásával.

A Renova funkció sebessége növelhető (↑) vagy (↓) csökkenthető a megfelelő ikonok megnyomásával. A Renova funkció automatikusan folytatja a fent leírt sorrendet a kiválasztott sebességtől kezdve.

Szűrőtisztítási figyelmeztető

Amikor a páraelszívó ki van kapcsolva, és az Időzítő ikon (☺) pirosan villog és a LED kijelzőn “(☐)” ikon jelenik meg, akkor a szűrőket meg kell tisztítani. Miután a szűrőket megtisztította vagy kicserélte, nyomja meg ismét az Időzítő (☺) ikont, és az ikon kialszik.

(Csak belső keringtető üzemmódban). Amikor a páraelszívó ki van kapcsolva, és az Időzítő ikon (☺) pirosan villog és a LED kijelzőn “(☐)” ikon jelenik meg, akkor a szűrőket meg kell tisztítani (ha mosható szénszűrőt használ), vagy ki kell cserélni azokat (ha eldobható szénszűrőt használ). Miután a szűrőket megtisztította vagy kicserélte, nyomja meg ismét az Időzítő ikont (☺), és az ikon kialszik.



Probléma	Lehetséges ok	Megoldás
Túlzott vibráció	A készülék nincs jól felszerelve a konzolokra.	Szerelje le a készüléket, és ellenőrizze, a rögzítést.
	A ventilátor lapátja sérült.	Kapcsolja ki a készüléket. A javítást kizárólag szakképzett szervizes szakember végezheti el.
	A ventilátormotor nincs szorosan rögzítve.	
A világítás működik, de a ventilátor nem indul el.	A ventilátor lapátja beragadt.	
	A motor sérült.	
Sem a világítás, sem a motor nem működik.	Kiégett a világítás.	Hívja az Ügyfélszolgálatot.
	Az áramellátás csatlakozása laza.	Ellenőrizze az áramellátást.
A szívóhatás csökkent.	A sebesség lehet túl alacsony.	Váltson nagyobb sebességre.
	Az opcionális szellőző készlet elcsavarodhatott.	Vizsgálja meg, hogy a szellőzőkészlet a gyártó utasításai szerint van-e felszerelve.
	A szellőzőnyílás elzáródott.	Távolítsa el minden akadályt
	A telepítés lehet, hogy nem felel meg a gyártó utasításainak.	A szellőzőcsőnek a teljes hosszában megfelelő átmérőjűnek kell lennie, szűkítés, akadály nélkül.
Normálisan működik, de a főzés szaga megmarad.	A szénzsűrő nincs megfelelően felszerelve, vagy zsírral van telítődve.	Szerelje be a szénzsűrőt, vagy cserélje ki a szénzsűrőt (lásd a Karbantartás és ápolás részt).
A páraelszívó nem működik.	Ellenőrizze, hogy a páraelszívó csatlakozik-e az áramforráshoz. Ellenőrizze a biztosítékokat vagy a kismegszakítót.	
Ha a páraelszívó továbbra sem működik,	Ha a fent említett pontok ellenőrzése után a problémája továbbra sem oldódott meg, forduljon a műszaki szervízhez vagy a forgalmazójához.	

Importőr:

MULTIKOMPLEX BUDAPEST KFT.

A páraelszívók szakértője... 1995 óta

H-1211 Budapest Mansfeld Péter utca 27.

tel.: (36-1) 427 0325

www.multikomplex.hu



www.cata.es



CATA ELECTRODOMÉSTICOS, S.L.

Oficinas: c/ Anabel Segura, 11, Edif. A, 3a pl. 28108. Alcobendas. Madrid. España

Fábrica: c/ del Ter 2, Apdo. 9. 08570. Torelló. Barcelona. España

T. +34 938 594 100 - Fax +34 938 594 101

www.cnagroup.es - cna@cnagroup.es

Atención al Cliente: 902 410 450 / +34 938 521 818 - info@cnagroup.es
International SAT - www.cnagroup.es/warranty



60820265.19.02.2024